

6-160 Compression Latch

lever actuated, flush



For the installation, the complete latch, including the pre-assembled U-shaped fastening bracket, is installed in the cutout from outside.

- By rotating the fastening screw from outside, the U-bracket automatically fastens the complete latch.
- In the "closed" position the screw can not be removed.
- The adjusting screw can also be used for retro-adjusting to increase or decrease the sealing pressure.

- **Attention:** Counternut for the adjusting screw: The standard position of the counternut is underneath the lever. Refer to A). On Request the counternut can be positioned on top of the lever. Refer B). If B) the max H-dimension decreases by about 4mm.
- PA version see product system 6-162.
- Vibration-proof to DIN EN 61373.

Material:

- **Compression Latch:** zinc die, black, powder coated
- **Other colors on request!**



